

Glass Safety

What are the issues?

Many homes built before 1989 do not meet Australian safety standards for glass, exposing families and children to unnecessary risk due in the event that a glass panel is broken exposing glass shards and splinters. Even though the Australian Standard AS1288 was introduced in 1989 the changes were not retrospective and there has been little effort to upgrade glass in existing homes.

Why is this an Issue Now?

Modern glass-making methods permit increasingly large areas of glass to be used in homes. There are many choices when it comes to glazing a new home or renovating an old one. Public awareness has simply not kept pace with the rapid expansion of glass possibilities.

This is no consolation to glass accident victims who generally learn after the event that the accident could have been prevented. Safety in any area where an accident might occur should be high on your list of priorities when selecting glass.

If the home was built before mid-1970s, it is unlikely that safety glass was installed.

Annealed Glass was used as the alternative and is often found in windows and feature areas. Other names used for this product can be sheet glass, plate glass, float glass and figured rolled glass. All are made by melting together a variety of raw materials, such as salt, sand and limestone and are produced in flat sheet of various sizes and thicknesses.

If the annealed glass is broken, regardless of its thickness, it fractures into sharp, jagged pieces. However, selected and installed correctly, it is perfectly satisfactory material for most uses, **except where there is a risk of violent contact.**



Safety Glass

The simplest way to prevent an accident is to be certain that one of two types of safety glass is used in any area (including shower screens) where there are risks:

- Grade A – Toughened & Laminated Safety Glass
- Grade B – Wired Safety Glass

These are covered by Australian Standard AS 1288:2006 *Glass in buildings—selection and installation* and AS/NZS 2208:1996 *Safety glazing materials in buildings*.

Since 1989 windows and other glazing installed in all new buildings have been required to meet mandatory specifications under Australian Standards.

Toughened glass offers 4 to 5 times the strength of ordinary glass of the same thickness. It is impact resistant and allows large clear spans with minimum fixing. In the unlikely event that the glass does break, it forms small particles, reducing the risk of injury.

When wired glass is broken, fragments of glass remain attached to the wire or will offer protection from injury by resisting penetration.

How to Identify What Glass is in Your Home?

- Check for labelling, all safety glass should be labelled.
- Contact an accredited glazier who will come to your home and identify the glazing type.



fact sheet

Safe Practices

It is relatively easy in a lot of glazed areas to prevent any bodily contact. This is particularly important where you suspect that annealed glass has been used in doors, side panels or low level glazing.

Low Level Glazing

- Protect by barrier rails or recessed sills.

Fixed Panels Along Side Doors

- Screen by furniture or plants.

Play or Social Areas

- Play or eat away from glazed areas.
- Use furniture that will not fall onto the glass, for example a table that will prevent direct contact. However, avoid using furniture that allows children to easily climb on, to gain access to the glass.

Visibility

- Choose any easy to see stickers- such as brightly coloured cartoon characters. Place the brightly coloured stickers at adult and child height on the glass sliding door and glass panel. The stickers can also be used in any other glazed area that you might be concerned about.
- Make sure that glass areas are well lit at all times, especially at night.
- Where transparent glass is not essential you can use a patterned, translucent glass.

Behaviour

- Treat glassed areas with respect.
- Set rules where the glass is not pushed on, banged into or slammed.
- Role model safe practices in glassed areas.

Environmental

- Maintain a trip-proof area. Remove toys and loose rugs.
- Keep inside and outdoor areas dry to prevent slipping into glass.

Shelves

- Seek advice on correct glass thickness for shelving.
- Ensure glass is adequately supported.
- Ensure edges are either protected or use rounded edges.
- If shelving is chipped or cracked replace immediately.

Short-Term Safety Measures for Existing Glass

If you are concerned that a glassed area in your home might be dangerous and do not wish to go the immediate expense of reglazing with a safety glass, you should consider taking other precautions, such as applying an organic-coated plastic safety & security film.



KIDSAFE NEW SOUTH WALES Inc.

Kidsafe House
Hainsworth Street
Locked Bag 4001
WESTMEAD NSW 2145
Ph: 02 9845 0890 Fax: 02 9845 0895
kidsafe@chw.edu.au
kidsafensw.org

Further information:

NSW Fair Trading fact sheet titled
Toughened Glass—safety guidelines for consumers
13 32 20
fairtrading.nsw.gov.au